

Factory Defaults Barcode. Scan this first.

2

Configuration Barcode. Scan this second.

3

1



*** Enable QR Code
(1)**

Use the following barcodes to turn QR code scanning ON/OFF

4



*** Enable QR Code
(1)**

5



**Disable QR Code
(0)**